

# CB-235

## CB ON-GLASS MOUNT ANTENNA

### INSTALLATION:

1. THE COUPLER BOX SHOULD BE A MINIMUM OF 1/2" FROM EDGE OF GLASS.
2. CLEAN GLASS INSIDE & OUTSIDE IN THE VICINITY OF MOUNTING AREA THOROUGHLY WITH ALCHOL SWAB TO REMOVE ALL GRIME AND GREASE.
3. THE MOUNTING TAPE WILL STICK INSTANTLY AND CANNOT BE REMOVED.
4. WHEN POSITIONED, FIRMLY PRESS THE BOX AGAINST THE GLASS AND HOLD FOR A FEW SECONDS.
5. POSITION ANTENNA WHIP VERTICAL, TIGHTEN SCREW, THAN REMOVE THE BACKING PAPER FROM THE MOUNTING FOOT CENTERED OVER COUPLER BOX. FIRMLY PRESS FOOT TO GLASS AND HOLD FOR FEW SECONDS.
6. ATTACH FEEDLINE AND ROUTE TO TRANSCEIVER LOCATION. SECURE THE COAX ALONG WINDOW MOLDING.

